

8. Vacuum Systems and TEM Holders**Problems**

8.1. Either an oil-diffusion pump (ODP) or turbomolecular pump (TMP) can be used to reach high vacuum. Describe advantages and disadvantages of each for use with a TEM. Mention ways the disadvantages can be addressed.
